



3rd Floor, Kalighat Park, IA, Anami Sangha,
Kalighat, Kolkata, West Bengal 700026

Phone: 9831 015 086

Quick Find Your TCL AC Error Codes

Two Columns: Error Codes & Meaning | Quick Solutions

Code	Meaning / Fault
E1	Indoor temperature sensor fault
E2	Indoor pipe temperature sensor fault
E3	Outdoor pipe temperature sensor fault
E4	Refrigerant system leakage or fault
E6	Malfunction of indoor fan motor
E7	Outdoor air temperature sensor fault
E8	Outdoor discharge temperature sensor fault
E9	Outdoor IPM module fault
ER	Outdoor current detect fault
EE	Outdoor PCB EEPROM fault
EF	Outdoor fan motor fault
EH	Outdoor suction temperature sensor fault